



Fitting A Gutter Edge Drip Plate

www.permaroof.co.uk



Fitting A Gutter Edge Drip Plate

In this tutorial, we're going to guide you on the fitting of the gutter edge drip plate.

Step 1

Make a mark around the edge of the roof, right where it falls over the sides.



In this example, there are curved edges on the other two dimensions. Trim all edges down to 50 mm.





Step 2

The drip plate is placed in position over the edge of the roof.



This traps the EPDM membrane between the back plate and the drip plate.

Step 3

The drip plate will secure on to a hook on the back plate and it will snap in to place and secure that edge completely.







Step 4

Tap into the entire length into place, and you're all done.



For more guides, videos and downloads please visit: www.permaroof.co.uk

Buy online: www.permaroofstore.co.uk