

PermaroofUK®

Membrane repair



Membrane repair

If the EPDM membrane is punctured, it is a simple procedure to make a waterproof repair.



Mark the area around the puncture at least 100mm in all directions.



Prime the marked area with Quickprime plus and a scrubber pad.



Cuts and punctures in the membrane should be repaired with cured cover strip. Cut out a piece of cover strip tape 75mm larger than the puncture and round off the corners. Remove the backing paper and apply over the puncture. Roll with the silicon hand roller.

